
You have been asked to model the plate shown in Figure 5–9.

Figure 5–9 Sketch of the skewed plate.



It is skewed 30° to the global 1-axis, is built-in at one end, and is constrained to move on rails parallel to the plate axis at the other end. You are to determine the midspan deflection when the plate carries a uniform pressure. You are also to assess whether a linear analysis is valid for this problem. You will perform an analysis using ABAQUS/Standard.

5.5.1 Preprocessing—creating the model with ABAQUS/CAE

Use ABAQUS/CAE to create the entire model for this simulation. A Python script is provided in "Skew plate," Section A.3. When this script is run through

ABAQUS/CAE, it creates the complete analysis model for this problem. Run this script if you encounter difficulties following the instructions given below or if you wish to check your work. Instructions on how to fetch and run the script are given in Appendix A, "Example Files."

If you do not have access to ABAQUS/CAE or another preprocessor, the input file required for this problem can be created manually, as discussed in "Example: skew plate," Section 5.5 of Getting Started with ABAQUS/Standard: Keywords Version.

Before you start to build the model, decide on a system of units. The dimensions are given in cm, but the loading and material properties are given in MPa and GPa. Since these are not consistent units, you must choose a consistent system to use in your model and convert the necessary input data. In the following discussion Newtons, meters, kilograms, and seconds are used.

Defining the model geometry

Start ABAQUS/CAE, and create a three-dimensional, deformable body with a planar shell base feature. Name the part Plate, and specify an approximate part size of 4.0. A suggested approach to creating the part geometry is outlined in the following procedure:

To sketch the plate geometry:


- In the Sketcher, create an arbitrary rectangle using the Create Lines:
 Rectangle tool.
- 2. Delete all constraints automatically imposed by the sketcher (four perpendicular constraints and one horizontal constraint).
- 3. Constrain the left and right edges to remain vertical and the bottom and top edges to be parallel.
- 4. Dimension the left edge by selecting the line and assign it a value of 0.4 m.
- 5. Dimension the bottom edge. Select the vertices of the line rather than the line itself to define a horizontal dimension. Set the horizontal distance between the vertices to 1.0 m.

Note: If you were to dimension the line itself, you would control only the length of the line (in whatever orientation it assumes).

6. Dimension the angle between the left and bottom edges. Select the left and bottom edges in succession, and set the value of the angle to 60°.

The final sketch is shown in Figure 5–10.

Figure 5–10 Sketch of the plate geometry (1 out of 2 grid lines visible).



7. In the prompt area, click **Done** to finish the sketch.

Defining the material and section properties and the local material directions

The plate is made of an isotropic, linear elastic material with a Young's modulus $E = 30 \times 10^9$ Pa and a Poisson's ratio $\nu = 0.3$. Create the material definition; name the material Metal.


The orientation of the structure in the global coordinate system is shown in Figure 5–9. The global Cartesian coordinate system defines the default material directions, but the plate is skewed relative to this system. It will not be easy to interpret the results of the simulation if you use the default material directions because the direct stress in the material 1-direction, σ_{11} , will contain contributions from both the axial stress, produced by the bending of the plate, and the stress transverse to the axis of the plate. It will be easier to interpret the

results if the material directions are aligned with the axis of the plate and the transverse direction. Therefore, a local rectangular coordinate system is needed in which the local x'-direction lies along the axis of the plate (i.e., at 30° to the global 1-axis) and the local y'-direction is also in the plane of the plate. Following the instructions given below, define the shell section properties in a local (nondefault) material coordinate system.

To define shell section properties and local material directions:

- 1. Define a homogeneous shell section named PlateSection. Specify that section integration be performed before the analysis since the material is linear elastic. Assign a shell thickness of 0.8E-2 and the Metal material definition to the section.
- 2. Define a rectangular datum coordinate system as shown in Figure 5–11 using the Create Datum CSYS: 2 Lines tool

Figure 5–11 Datum coordinate system used to define local material directions.



3. From the main menu bar of the Property module, select Assign— Material Orientation and select the entire part as the region to which local material directions will be applied. In the viewport, select the datum coordinate system created earlier. Select Axis—3 for the direction of the approximate shell normal. No additional rotation is needed about this axis.

Tip: To verify that the local material directions have been assigned correctly, select **Tools→Query** from the main menu bar and perform a property query on the material orientations. Triads appear in the viewport indicating the material orientation of the region you select.

Once the part has been meshed and elements have been created in the model, all element variables will be defined in this local coordinate system.

4. Finally, assign the section definition to the plate.

Creating an assembly, defining an analysis step, and specifying output requests


Create a dependent instance of the plate.

You will partition the plate in half at its midspan; this will allow you to define a set there. You will also define additional assembly-level sets to facilitate other output request and boundary condition definitions.

To partition the plate and define geometry sets:

- In the Model Tree, double-click the Plate item in the Parts container to make it current.

Figure 5–12 Partition used to define a geometry set at the plate midspan.



3. In the Model Tree, expand the **Assembly** container and double-click the **Sets** item to create a geometry set for the midspan named MidSpan. Similarly, create sets for the left and right edges of the plate and name them EndA and EndB, respectively. The locations of these three sets are indicated in Figure 5–12.

Tip: Geometry sets can be reviewed by expanding the **Sets** item underneath the **Assembly** container in the Model Tree and then double-clicking on the set name in the list that appears. The selected set is highlighted in the viewport, and its definition can be edited if necessary.

Next, create a single static, general step. Name the step Apply Pressure, and specify the following step description: Uniform pressure (20 kPa) load. Accept all the default settings for the step.

Among the output you will need are the nodal displacements, reaction forces, and element stresses as field data. These data will be used to create deformed shape plots, contour plots, and tabular data reports in the Visualization module. You will also want to write the displacements at the midspan as history data to create X-Y plots in the Visualization module.

To change the default output requests:

- Edit the field output request so that only the nodal displacements, reaction forces, and element stresses for the whole model are written as field data to the .odb file.
- 2. Edit the history output request so that only the vertical nodal displacements **U3** for the set named MidSpan are written as history data to the .odb file.

Prescribing boundary conditions and applied loads

As shown in Figure 5–9, the left end of the plate is completely fixed; the right end is constrained to move on rails that are parallel to the axis of the plate. Since the latter boundary condition direction does not coincide with the global axes, you must define a local coordinate system that has an axis aligned with the plate. You can use the datum coordinate system that you created earlier to define the local material directions.

To assign boundary conditions in a local coordinate system:

- In the Model Tree, double-click the BCs container and define a
 Displacement/Rotation mechanical boundary condition named Rail boundary condition in the Apply Pressure step.
 - In this example you will assign boundary conditions to sets rather than to regions selected directly in the viewport. Thus, when prompted for the regions to which the boundary condition will be applied, click **Sets** in the prompt area of the viewport.
- From the Region Selection dialog box that appears, select set EndB.
 Toggle on Highlight selections in viewport to make sure the correct set is

selected. The right edge of the plate should be highlighted. Click **Continue**.

- 3. In the Edit Boundary Condition dialog box, click Edit to specify the local coordinate system in which the boundary condition will be applied. In the viewport, select the datum coordinate system that was created earlier to define the local directions. The local 1-direction is aligned with the plate axis.
- 4. In the **Edit Boundary Condition** dialog box, fix all degrees of freedom except for **U1**.

The right edge of the plate is now constrained to move only in the direction of the plate axis. Once the plate has been meshed and nodes have been generated in the model, all printed nodal output quantities associated with this region (displacements, velocities, reaction forces, etc.) will be defined in this local coordinate system.


Complete the boundary condition definition by fixing all degrees of freedom at the left edge of the plate (set **EndA**). Name this boundary condition Fix left end. Use the default global directions for this boundary condition.

Finally, define a uniform pressure load across the top of the shell named Pressure. Select both regions of the part using **[Shift]+Click** and then click **Done**. When prompted to choose a side for the shell or internal faces, select **Brown**, which corresponds to the top side of the plate. You may need to rotate the view to more clearly distinguish the top side of the plate. Specify a load magnitude of 2.E4 Pa.

Creating the mesh and defining a job

Figure 5–13 shows the suggested mesh for this simulation.

Figure 5–13 Suggested mesh design for the skewed plate simulation.



You must answer the following questions before selecting an element type: Is the plate thin or thick? Are the strains small or large? The plate is quite thin, with a thickness-to-minimum span ratio of 0.02. (The thickness is 0.8 cm and the minimum span is 40 cm.) While we cannot readily predict the magnitude of the strains in the structure, we think that the strains will be small. Based on this information, choose quadratic shell elements (S8R5) because they give accurate results for thin shells in small-strain simulations. For further details on shell element selection, refer to "Choosing a shell element," Section 23.6.2 of the ABAQUS Analysis User's Manual.

In the Model Tree, expand the **Plate** item underneath the **Parts** container and double-click **Mesh** in the list that appears. Seed the part using a global element size of 0.1. From the main menu bar, select **Mesh—Controls** to specify the structured mesh technique for this model. Create a quadrilateral mesh using quadratic, reduced-integration shell elements with five degrees of freedom per node (S8R5).

Before proceeding, rename the model to Linear. This model will later form the basis of the model used in the skew plate example discussed in Chapter 8, "Nonlinearity."

Define a job named SkewPlate with the following description:

Linear Elastic Skew Plate, 20 kPa Load.

Save your model in a model database file named SkewPlate.cae.

Submit the job for analysis, and monitor the solution progress; correct any modeling errors detected by the analysis product, and investigate the cause of any warnings.

5.5.2 Postprocessing

This section discusses postprocessing with ABAQUS/CAE. Both contour and symbol plots are useful for visualizing shell analysis results. Since contour plotting was discussed in detail in Chapter 4, "Using Continuum Elements," we use symbol plots here.

In the **Module** list located under the toolbar, click **Visualization** to enter the Visualization module. Then, open the .odb file created by this job (SkewPlate.odb). By default, ABAQUS/CAE plots the undeformed shape of the model.

Element normals

Use the undeformed shape plot to check the model definition. Check that the element normals for the skew-plate model were defined correctly and point in the positive 3-direction.

To display the element normals:

1. From the main menu bar, select **Options**→**Common**; or use the in the toolbox.

The **Common Plot Options** dialog box appears.

- 2. Click the **Normals** tab.
- 3. Toggle on **Show normals**, and accept the default setting of **On elements**.

4. Click **OK** to apply the settings and to close the dialog box.

The default view is isometric. You can change the view using the options in the view menu or the view tools (such as) from the toolbar.

To change the view:


1. From the main menu bar, select View—Specify.

The **Specify View** dialog box appears.

- 2. From the list of available methods, select Viewpoint.
- 3. Enter the X-, Y- and Z-coordinates of the viewpoint vector as -0.2, -1, 0.8 and the coordinates of the up vector as 0, 0, 1.
- 4. Click OK.

ABAQUS/CAE displays your model in the specified view, as shown in Figure 5–14.

Figure 5–14 Shell element normals in skewed plate model.



Symbol plots

Symbol plots display the specified variable as a vector originating from the node or element integration points. You can produce symbol plots of most tensorand vector-valued variables. The exceptions are mainly nonmechanical output variables and element results stored at nodes, such as nodal forces. The relative size of the arrows indicate the relative magnitude of the results, and the vectors are oriented along the global direction of the results. You can plot results for the resultant of variables such as displacement (U), reaction force (RF), etc.; or you can plot individual components of these variables.

To generate a symbol plot of the displacement:

1. From the main menu bar, select Result→Field Output.

The **Field Output** dialog box appears; by default, the **Primary Variable** tab is selected.

- 2. From the list of output variables, select **U**.
- 3. From the list of components, select **U3**.
- 4. Click OK.

The **Select Plot State** dialog box appears.


5. Toggle on **Symbol**, and click **OK**.

ABAQUS/CAE displays a symbol plot of the displacement vector resultant on the deformed model shape.

- 6. The default shaded render style obscures the arrows. An unobstructed view of the arrows can be obtained by changing the render style to Wireframe using the Common Plot Options dialog box. If the element normals are still visible, you should turn them off at this time.
- The symbol plot can also be based on the undeformed model shape.
 From the main menu bar, select Plot—Symbols—On Undeformed
 Shape.

A symbol plot on the undeformed model shape appears, as shown in Figure 5–15.

Figure 5–15 Symbol plot of displacement.



You can plot principal values of tensor variables such as stress using symbol plots. A symbol plot of the principal values of stress yields three vectors at every integration point, each corresponding to a principal value oriented along the corresponding principal direction. Compressive values are indicated by arrows pointing toward the integration point, and tensile values are indicated by arrows pointing away from the integration point. You can also plot individual principal values.

To generate a symbol plot of the principal stresses:

- 1. From the main menu bar, select Result→Field Output.
 - The **Field Output** dialog box appears.
- 2. From the list of output variables, select **S**; and from the list of invariants, select **Max. Principal**.

3. Click **OK** to apply the settings and to close the dialog box.

ABAQUS/CAE displays a symbol plot of principal stresses.


4. From the main menu bar, select **Options**—**Symbol**; or use the **Symbol Options** tool in the toolbox to change the arrow length.

The **Symbol Plot Options** dialog box appears.

- 5. In the Color & Style page, click the Tensor tab.
- 6. Drag the **Size** slider to select 2 as the arrow length.
- 7. Click **OK** to apply the settings and to close the dialog box.

The symbol plot shown in Figure 5–16 appears.


Figure 5–16 Symbol plot of principal stresses on the bottom surface of the plate.



- 8. The principal stresses are displayed at section point 1 by default. To plot stresses at nondefault section points, select **Result—Section Points** from the main menu bar to bring up the **Section Points** dialog box.
- 9. Select the desired nondefault section point for plotting.

10. In a complex model, the element edges can obscure the symbol plots. To suppress the display of the element edges, choose Feature edges in the Basic tabbed page of the Common Plot Options dialog box. Figure 5–17 shows a symbol plot of the principal stresses at the default section point with only feature edges visible.

Figure 5–17 Feature edge plot showing vectors of principal stress.



Material directions

ABAQUS/CAE also lets you visualize the element material directions. This feature is particularly helpful, allowing you to ensure the correctness of the material directions.

To plot the material directions:

From the main menu bar, select Plot
 Material Orientations
 On
 Undeformed Shape; or use the toolbox.

The material orientation directions are plotted on the undeformed shape. By default, the triads that represent the material orientation directions are plotted without arrowheads.

2. From the main menu bar, select **Options** Material **Orientation**; or use the **Material Orientation Options** tool in the toolbox to display the triads with arrowheads.

The Material Orientation Plot Options dialog box appears.


- 3. Set the **Arrowhead** option to use filled arrowheads in the triad.
- 4. Click **OK** to apply the settings and to close the dialog box.
- 5. From the main menu bar, select **View→Views Toolbox**; or click the tool in the toolbar.

The Views toolbox appears.

6. Use the predefined views available in the toolbox to display the plate as shown in Figure 5-18. In this figure, perspective is turned off. To turn off perspective, click the toolbar.

By default, the material 1-direction is colored blue, the material 2-direction is colored yellow, and, if it is present, the material 3-direction is colored red.

Figure 5–18 Plot of material orientation directions in the plate.



Evaluating results based on tabular data

Additional postprocessing can be performed by examining printed data. With the aid of display groups, create a tabular data report of the whole model element stresses (components S11, S22, and S12), the reaction forces at the supported nodes (sets EndA and EndB), and the displacements of the midspan nodes (set MidSpan). The stress data are shown below.

Field Output Report

```
Source 1
```

ODB: SkewPlate.odb Step: Apply pressure

Frame: Increment 1: Step Time = 1.000

Loc 1 : Integration point values at shell general ... : SNEG, (fraction = -1.0)

Loc 2 : Integration point values at shell general ... : SPOS, (fraction = 1.0)

Output sorted by column "Element Label".

Field Output reported at integration points for part: PLATE-1

 Element
 Int
 S.S11
 S.S11
 S.S22
 S.S22
 S.S12
 S.S12

 Label
 Pt
 @Loc 1
 @Loc 2
 @Loc 2
 @Loc 1
 @Loc 2

- 1 1 79.7614E+06 -79.7614E+06 1.1085E+06 -1.1085E+06 -5.86291E+06 5.86291E+06
- 1 2 83.7703E+06 -83.7703E+06 7.14559E+06 -7.14559E+06 -8.00706E+06 8.00706E+06
- 1 3 66.9385E+06 -66.9385E+06 2.79241E+06 -2.79241E+06 -1.98396E+06 1.98396E+06
- 1 4 72.3479E+06 -72.3479E+06 5.05957E+06 -5.05957E+06 -7.0819E+06 7.0819E+06

.

- 48 1 -142.755E+06 142.755E+06 -56.0747E+06 56.0747E+06 21.007E+06 21.007E+06
- 48 2 -118.848E+06 118.848E+06 -7.21449E+06 7.21449E+06 4.00065E+06 4.00065E+06
- 48 3 -187.19E+06 187.19E+06 -103.31E+06 103.31E+06 50.352E+06 50.352E+06
- 48 4 -238.323E+06 238.323E+06 -84.7331E+06 84.7331E+06 70.0676E+06 70.0676E+06

Minimum -238.323E+06 -90.2378E+06 -103.31E+06 -10.5216E+06 -18.865E+06 -70.0676E+06

At Element 48 4 24 2 12 48

Int Pt 4 4 3 2 4 4

Maximum 90.2378E+06 238.323E+06 10.5216E+06 103.31E+06 70.0676E+06 18.865E+06

At Element 4 48 2 24 48 12

Int Pt 4 4 2 3 4 4

The locations Loc 1 and Loc 2 identify the section point in the element where the stress was calculated. Loc 1 (corresponding to section point 1) lies on the SNEG surface of the shell, and Loc 2 (corresponding to section point 3) lies on the SPOS surface. Local material directions have been used for the element: the stresses refer to a local coordinate system.

Check that the small-strain assumption was valid for this simulation. The axial strain corresponding to the peak stress is $\varepsilon_{11} \approx 0.0079$. Since the strain is typically considered small if it is less than 4 or 5%, a strain of 0.0079 is well within the appropriate range to be modeled with S8R5 elements.

Look at the reaction forces and moments in the following table: Field Output Report

Source 1

ODB: SkewPlate.odb Step: Apply pressure

Frame: Increment 1: Step Time = 1.000

Loc 1: Nodal values from source 1

Output sorted by column "Node Label".

Field Output reported at nodes for part: PLATE-1

Node	RF.RF1		RF.RF2	RF.RF3	RM.RM1	RM.RM2	RM.RM3
Label	@Loc 1		@Loc 1	@Loc 1	@Loc 1	@Loc 1	@Loc 1
3	0.	0.	37.3924	-1.5991	-76.4939	0.	
4	0.	0.	-109.834	1.77236	-324.424E-0	3 0.	
5	0.	0.	37.3918	1.59909	76.4939	0.	
6	0.	0.	-109.834	-1.77236	324.411E-0	3 0.	
15	0.	0.	73.6366	8.75019	-62.2243	0.	
16	0.	0.	260.424	6.95105	-51.1181	0.	
17	0.	0.	239.685	6.56987	-35.4374	0.	
28	0.	0.	73.6366	-8.75019	62.2243	0.	
29	0.	0.	260.424	-6.95105	51.1181	0.	
30	0.	0.	239.685	-6.56988	35.4374	0.	
116	0.	0	6.15382	7.5915	-36.4274	0.	

```
119
         0.
                  0.
                       455.132
                                  6.80781
                                                            0.
                                              -88.237
121
         0.
                  0.
                       750.805
                                  8.31069
                                             -126.462
                                                            0.
                  0. 2.2866E+03
                                                              0.
123
         0.
                                    31.0977
                                               -205.818
170
         0.
                  0.
                        6.154
                                 -7.5915
                                            36.4274
                                                          0.
                  0.
173
         0.
                       455.133
                                  -6.80782
                                              88.237
                                                           0.
175
                                                            0.
         0.
                  0.
                       750.805
                                  -8.31069
                                              126.462
177
                                                              0.
         0.
                  0. 2.2866E+03
                                    -31.0977
                                                205.818
```

Total 0. 0. 8.00000E+03-39.2199E-06-5.00679E-06 0.

The reaction forces are written in the global coordinate system. Check that the sum of the reaction forces and reaction moments with the corresponding applied loads is zero. The nonzero reaction force in the 3-direction equilibrates the vertical force of the pressure load (20 kPa \times 1.0 m \times 0.4 m). In addition to the reaction forces, the pressure load causes self-equilibrating reaction moments at the constrained rotational degrees of freedom.

The table of displacements (which is not shown here) shows that the midspan deflection across the plate is approximately 5.3 cm, which is approximately 5% of the plate's length. By running this as a linear analysis, we assume the displacements to be small. It is questionable whether these displacements are truly small relative to the dimensions of the structure; nonlinear effects may be important, requiring further investigation. In this case we need to perform a geometrically nonlinear analysis, which is discussed in Chapter 8, "Nonlinearity."